

WINDSOR

CHARIOT 2 iSCRUB 20



MAINTENANCE

86372390



01) Drain and rinse out the recovery tank.



02) Clean the float shut off.



03) Remove squeegee and inspect blades. If the squeegee is damaged, flip the blade or replace.



04) Clean squeegee.



05) Check pad for wear and change when necessary. Pads should be replaced when they get to be 1/2".



06) Take a clean rag and wipe down the exterior of the machine.



07) Plug the batteries back into the charger and maintain if necessary.



OPERATION

86372390



01) Unplug the batteries from the charger and plug the batteries into the machine.



02) Fill solution tank with water and measured chemicals.



03) Put the key into the ignition and turn the machine on.



04) Choose operation mode. FROM LEFT TO RIGHT: slow transport, fast transport, A1, A2, pick up only, and double scrub.



05) Step onto platform and press green pedal to move.



06) Select direction (forward or reverse).



07) IN CASE OF EMERGENCY: press the red button to stop the machine.